



## What to do... File Menu Always Shows "Fax"

### **Introduction:**

The following document provides information about what to do when your Macintosh's File menu always shows "Fax" where "Print" normally is.

If your Macintosh's File menu always shows "Fax" where "Print" normally is, follow the troubleshooting steps below.

1. Open your **Chooser** and re-select the printer driver you normally use.
2. Close the Chooser, and save changes if prompted.

From the desktop or any application, click on the **File** menu. The "Print" (or "Print Desktop") command should now display in your File menu, and you should be able to print normally.

In very rare cases, if "Print" still does not show in the File menu, then you may have corrupt GlobalFax software or system software. For instructions on how to reinstall GlobalFax software, please download document #2008, "How to... Clean Reinstall GlobalFax Software."